

KEYBOARD CONTROLS

SET: Displays target **SET POINT**. Pushing & releasing the key will display the set point for 5 seconds.

To modify SET POINT: Press & hold the key for at least 2 sec, this will display the set point and the DOTs of the first and third flashing digits. To modify the value use the "UP" & "DOWN" keys. Having set a new value this can be memorised by either pressing SET (the display reverts to the controlled variable) or by waiting for the Exit time out (15 secs).

▲ UP: In either programming or "Menu Functioning" mode scrolls the parameter codes or increases the value of the displayed variable. Holding it pressed will increase the speed.

To display the alarms happened: holding it pressed for more than 3 secs during normal running, the code of the first alarm will be displayed. Use the **UP** and **DOWN** keys to browse the recorded alarms.

▼ DOWN: In either programming or "Menu Functioning" mode scrolls the parameter codes or decreases the value of the displayed variable. Holding it pressed will increase the speed.



CLOCK: Displays the compressor run times. Holding it pressed for 3 secs will display in sequence the hour run times of each compressor.

When a load reaches the maximum run time hours set in the **HrC** parameter, the label HrCx is displayed, with x is related to the load.

Key combinations:

▲ + ▼ Unlocks the keyboard (after it has been locked by an appropriate function in the menu). Hold them pressed for 3 secs. "POn" will appear flashing on the display for a few seconds and the keyboard will be unlocked.

SET + ▼ Access to the "Functions Menu". Hold pressed for 3 secs.

SET + ▲ Exit from programming of parameter "Pr1" or "Pr2": Holding SET+UP pressed with a parameter displayed will exit programming mode and return to displaying the controlled variable.