

**XH130C - XH131C - XH130D - XH131D - XH131R**

**Dead Band Controller For Relative Humidity**

CONTENTS:

1. GENERAL WARNING \_\_\_\_\_ 1  
 1.1 Please read before using this manual \_\_\_\_\_ 1  
 1.2 Safety Precautions \_\_\_\_\_ 1

2. GENERAL DESCRIPTION \_\_\_\_\_ 1

3. REGULATIONS \_\_\_\_\_ 1

4. FRONT PANEL COMMANDS \_\_\_\_\_ 2  
 4.1 Use of LEDS \_\_\_\_\_ 2

5. FUNCTION AND PARAMETERS' PROGRAMMING MENU \_\_\_\_\_ 2  
 5.1 Function Menu \_\_\_\_\_ 2  
 5.2 List of functions \_\_\_\_\_ 2  
 5.3 Exit Timeout \_\_\_\_\_ 2  
 5.4 Accessing "Pr2" and SECURITY CODE input \_\_\_\_\_ 2  
 5.5 Changing a parameter's value \_\_\_\_\_ 2

6. LIST OF PARAMETERS \_\_\_\_\_ 2

7. INSTALLATION AND MOUNTING \_\_\_\_\_ 3

8. ELECTRICAL CONNECTIONS \_\_\_\_\_ 3  
 8.1 Probes connection \_\_\_\_\_ 3

9. ALARM SIGNALS \_\_\_\_\_ 3  
 9.1 Status of the alarm relay \_\_\_\_\_ 3  
 9.2 Silencing buzzer / alarm relay output \_\_\_\_\_ 3  
 9.3 Alarm recovery \_\_\_\_\_ 3

10. TECHNICAL DATA \_\_\_\_\_ 3

11. CONNECTIONS \_\_\_\_\_ 4

12. \_\_\_\_\_ 5

12. DEFAULT SETTING VALUES \_\_\_\_\_ 5

**1. GENERAL WARNING**

**1.1 ⚠ Please read before using this manual**

- This manual is part of the product and should be kept near the instrument for easy and quick reference.
- The instrument shall not be used for purposes different from those described hereunder. It cannot be used as a safety device.
- Check the application limits before proceeding.

**1.2 ⚠ Safety Precautions**


- Check the supply voltage is correct before connecting the instrument.
- Do not expose to water or moisture: use the controller only within the operating limits avoiding sudden temperature changes with high atmospheric humidity to prevent formation of condensation
- Warning: disconnect all electrical connections before any kind of maintenance.
- The instrument must not be opened.
- In case of failure or faulty operation send the instrument back to the distributor or to "DIXELL s.r.l." (see address) with a detailed description of the fault.
- Consider the maximum current which can be applied to each relay (see Technical Data).
- Ensure that the wires for probes, loads and the power supply are separated and far enough from each other, without crossing or intertwining.
- In case of applications in industrial environments, the use of mains filters (our mod. FT1) in parallel with inductive loads could be useful.

**2. GENERAL DESCRIPTION**

The XH130C, XH131C (32x74 format), XH130D, XH131D (DIN RAIL format) and XH131R (72x72 format), are versatile microprocessor-based ON/OFF instruments. They have been developed and designed for applications in the industrial sector where the process variable must be maintained constant within a fixed band. These controllers are suitable in particular for the ON/OFF control of unstable process variable (over and under shooting) which require the intervention of systems with direct and inverse action to maintain within a "deadband".

**3. REGULATIONS**

- two stage ON/OFF control with DEAD BAND
- relay 1 output at inverse action (humidification,): load 1 CUT IN is "SET-db", load 1 CUT OUT is when the process variable reaches the set point.
- relay 2 output at direct action (dehumidification,): load 2 CUT IN is "SET+db", load 2 CUT OUT is when the process variable reaches the set point.



**4. FRONT PANEL COMMANDS**

**SET: TO DISPLAY TARGET SET POINT:** by pressing and releasing this key the set point is displayed for 5s.

**TO MODIFY SET POINT:** by holding the key pressed for at least 2s set point change mode is entered: the set point is displayed and the LEDs of the first and third digits blink. To change the value use the **“UP”** and **“DOWN”** keys. The new value can be stored either by pressing the **“SET”** key (the instrument restores normal display) or by waiting the exit time-out to expire (15s).

**TO SWITCH THE INSTRUMENT ON/OFF:** If the function is enabled (par. OnF=1), by pressing the SET key for more than 4s the controller is switched OFF. To switch the instrument on again press the SET key.

**▲ (UP):** In programming mode or in **“Function Menu”** it browses the parameter codes or increases the value of the displayed variable. Hold pressed for a faster change.

**▼ (DOWN):** in programming mode or in **“Function Menu”** it browses the parameter codes or decreases the value of the displayed variable. Hold pressed for a faster change.

**KEY COMBINATIONS:**


**▲+ ▼ TO UNLOCK THE KEYBOARD:** when held pressed for 3s the keyboard is unlocked (see **“LOC”** function).

**SET + ▼ TO ENTER ON FUNCTION MENU:** when held pressed for 3s the Function Menu is entered.

**SET + ▲ TO RETURN TO THE PROCESS VARIABLE DISPLAY:** programming end, return to the process variable display.

**4.1 Use of LEDs**

A series of light points on the front panels is used to monitor the loads controlled by the instrument. Each LED function is described in the following table.



LED	MODE	FUNCTION
	ON	Output 1 enabled
	ON	Output 2 enabled
	ON	Process variable in the dead band
LED1	FLASHING	- Programming Phase (flashing with LED2)
	ON	- ALARM signal - In <b>“Pr2”</b> indicates the parameter is also present in <b>“Pr1”</b>

**5. FUNCTION AND PARAMETERS' PROGRAMMING MENU**

**5.1 Function Menu**

Includes all the main functions controlled by the instrument.

**Access procedure:**

- The menu is entered by holding the **SET** and **DOWN** keys pressed for three seconds. The label of the first function is displayed.
- The **UP** and **DOWN** keys are used to cycle backwards or forward in the menu.
- By pressing the **SET** key the currently displayed function is enabled.

**5.2 List of functions**

1. **“Pr1”**: includes all user accessible parameters.

2. **“Pr2”**: includes all the instrument's parameters (at installer level). It can be accessed through a security code. Hence it is possible to modify all parameters and add or remove parameters from **“Pr1”** (user level) by pressing **“SET”** + **“DOWN”**. When a parameter is enabled at user level, (Alarm LED) is on during programming mode in Pr2.
3. **“LOC”**: keyboard lock. When enabled the **“POF”** flashing message is displayed for a few seconds then the keys are locked. Only the set point display is enabled.
4. **“Out”**: exits from menu.

**5.3 Exit Timeout**

If no key is pressed for more than 15 seconds the instrument reverts to normal display mode.

**5.4 Accessing “Pr2” and SECURITY CODE input**

To access parameters in **“Pr2”** a security code is required.

1. Enter Function Menu, select label **“Pr2”** and press the **“SET”** key. The **“PAS”** flashing message is displayed, shortly followed by **“0 - -”** with a flashing zero.
2. Use **“UP”** or **“DOWN”** to input the security code in the flashing digit;
3. Confirm the figure by pressing **“SET”**.
4. Repeat operations 2 and 3 for the other digits.
5. If the security code is correct the access to **“Pr2”** is enabled by pressing **“SET”** on the last digit, otherwise the security code input process restarts from the beginning.

If no key is pressed for more than 15 seconds the instrument reverts to normal display mode.

**SECURITY CODE is 321**

**NOTE:** each parameter in **“Pr2”** can be removed and put into **“Pr1”** (user level) by pressing **“SET”** + **“DOWN”**. When a parameter is present in **“Pr1”** ALARM LED is on during programming mode in Pr2..

**5.5 Changing a parameter's value**

Each parameter is identified by a special alphanumeric code.

To change the parameter's value operate as follows:

1. Enter the Function Menu and select the parameters' list you require: **“Pr1”** or **“Pr2”**.
2. Browse the parameters' list using **“UP”** or **“DOWN”** until the required parameter is displayed.
3. Press the **“SET”** key to display its value.
4. Use **“Up”** or **“DOWN”** to change its value.
5. Press **“SET”** to store the new value and move to the following parameter.

**To exit:** Press **SET + UP** or wait 15s without hitting a key.

**NOTE:** the set value is stored even when the procedure is exited by waiting the timeout to expire.

**6. LIST OF PARAMETERS**

- db dead band width:** (1÷Full Scale) this is the band below and above the set point beyond which the relay 1 respectively relay 2 are enabled. Once a output is enabled, it remains ON until the set point is reached.
- LS1 Minimum set point:** (Down Sc./ Set) Sets the minimum acceptable value for the set point.
- US1 Maximum set point:** (Set/ Full Sc.) Sets the maximum acceptable value for set point.
- ALU Maximum alarm:**  
  - with ALC=0:** alarm relative to set point, (0÷|Full Sc.-Set|) Maximum alarm is enabled when the humidity exceeds the **“SET+ALU”** value.
  - with ALC=1:** absolute alarm, (Set÷Full Sc.) Maximum alarm is enabled when the humidity exceeds the **“ALU”** value.
- ALL Minimum alarm:** (Down Sc./ Full Sc.) **with ALC=0:** relative to set point, (0÷|Down Sc.-Set|) this value is subtracted from the set point. The alarm signal is enabled when the humidity goes below the **“SET-ALL”** value.  
  - with ALC=1** (absolute) minimum alarm is enabled when the humidity goes below the **“ALL”** value.

- Ald Alarm delay:**(0÷999 min) time interval between the detection of an alarm condition and alarm signalling.
- dAO Delay of alarm at start-up:** (0÷999 min) time interval between the detection of the alarm condition after instrument power on and alarm signalling.
- od Output delay:** (0÷500 sec) minimum interval between the load stop and the following restart.
- LCI Start of scale with current or voltage input:** (-999÷999). Adjustment of read out corresponding to 4mA or 0V input signal.
- UCI End of scale with current or voltage input** (-999÷999). Adjustment of read out corresponding to 20mA or 1V or 10V input signal.
- LAO Lower analog output limit: (only for models with analog output)** minimum value of humidity associated to the 4mA (or 0V) analog output. This value can be absolute or relative to the Set Point 1 by setting the AOC parameter.
- UAO Upper analog output limit: (only for models with analog output)** maximum value of humidity associated to the 20mA (or 5V) analog output. This value can be absolute or relative to the Set Point 1 by setting the AOC parameter.
- OPb Probe calibration:** (-999÷999) allows to adjust possible offset of the probe.
- Ad1..Ad2: RS485 serial address (0÷94):** identifies the instrument within a control or supervising system.
- AOC Analog output configuration:**  
**AOC=0 Probe reading.** The analog output parameters LAO and UAO are independent and correspond to the absolute read-out probe signal.  
**AOC=1 Probe - Set Point1.** The analog output parameters LAO and UAO are related to the difference between measurement of the probe and Set Point 1.
- So1 Relay 1 status 1 with faulty probe:**  
So1=0 open; So1=1 close.
- So2 Relay 2 status with faulty probe:**  
So2=0 open; So2=1 close.
- Hdd Half digit display:** (Hdd=0 OFF; Hdd=1 ON)the right hand digit can be set to read out only 0 or 5, or to read out all values from 0 to 9.  
E.g. if **Hdd= 0** the displayed values could be: 231, 232, 233...  
if **Hdd= 1** the displayed values could be 230, 235, 240...
- rES Decimal point ON/OFF:** (0=no decimal point; 1=with d. p.) select the resolution of the controller: with decimal point or without decimal point.  
**NOTE:** on all models, if a unit is changed from "without decimal point" into "with decimal point", all parameters values expressed percent of humidity (**SET, db, LS1, US1, ALU, ALL, LCI, UCI, LAO, UAO, OPb**) will automatically be divided by 10.  
**To restore the right behaviour** multiplie by 10 the above parameters.
- ALC Set point alarms configuration:**  
(0= relative to set point; 1=absolute) determines if alarms are relative to set point or referred to absolute values.
- SAO Analog output safety with probe fault:** determines what state the analog output should assume when the probe is faulty: SAO = 0; analog output = 4mA or 0Vdc .  
SAO = 1; analog output = 20mA or 1Vdc.
- Ptb Parameters table:** (read only) Shows the factory default settings.
- rEL Software release:** (read only)

**7. INSTALLATION AND MOUNTING**

Instruments **XH130C, XH131C**, are panel mounted, in a 29x71 mm hole, and fixed using the special bracket supplied.  
 Instruments **XH130D, XH131D**, shall be mounted on an omega DIN rail (3).  
 Instrument **XH131R** is panel mounted, in a 69x69 mm hole, and fixed using the special bracket supplied.  
 The ambient temperature range allowed for correct operation is 0÷60°C (32÷140°F). Avoid places subject to strong vibrations, corrosive gases, excessive dirt or humidity. Let air circulate by the cooling holes.

**8. ELECTRICAL CONNECTIONS**

The instruments are provided with screw terminal block to connect cables with a cross section up to 2,5 mm<sup>2</sup>. Before connecting cables make sure the power supply complies with the instrument's requirements. Separate the input connection cables from the power supply cables, from the outputs and the power connections. Do not exceed the maximum current allowed on each relay, in case of heavier loads use a suitable external relay.

**8.1 Probes connection**

The PTC probes shall be mounted with the bulb upwards to prevent damages due to casual liquid infiltration.

**9. ALARM SIGNALS**

Message - Mode	Cause	Outputs
"ooo" Flashing	Probes break or absence	Alarm output ON; Relay output according to parameters "So1"
"CCC" Flashing	Probe shorted circuit	Alarm output ON; Relay output according to parameters "So1"
"HA" Alternating with normal display	Maximum alarm	Alarm output ON; Other outputs unchanged.
"LA" Alternating with normal display	Minimum alarm	Alarm output ON; Other outputs unchanged.

**9.1 Status of the alarm relay**

MODE	RELAY STATUS
Instrument OFF	Closed
Normal operating mode	Open
Alarm occurring	Closed

**9.2 Silencing buzzer / alarm relay output**

Once the alarm signal is detected the buzzer and the alarm output can be disabled by pressing any key. The display signal remains as long as the alarm condition remains.

**9.3 Alarm recovery**

Probe alarms "ooo", "CCC" start 30 seconds after the fault in the probe; they automatically stop 30 seconds after the probe restarts normal operation. Check connections before replacing the probe.  
 Max. and min. alarms "HA" and "LA" automatically stop as soon as the variable returns to normal values.

**10. TECHNICAL DATA**

**Housing:** self extinguishing ABS.

**Case:**

- XH130C, XH131C** frontal 32x74 mm; depth 60mm;
- XH130D, XH131D:** 4 DIN modules 70x85 mm; depth 61mm.
- XH131R:** frontal 72x72, depth 100mm

**Mounting:**

- XH130C, XH131C** panel mounting in a 71x29 mm panel cut-out.
- XH130D, XH131D:** DIN RAIL
- XH131R:** panel mounting in a 68x68 mm panel cut-out.

**Frontal protection:** IP65

**Connections:** Screw terminal block ≤ 2,5 mm<sup>2</sup> wiring.

**Power supply:**

- XH130C, XH131C:** 12Vac/dc, -10% +15% 50/60Hz. (Opt. 24Vac/dc)
- XH130D, XH131D, XH131R:** 110/230Vac 50/60Hz (Opt. 24Vac/dc)

**Power absorption:** 3VA max.

**Display**

3 digits, red LED, 14,2 mm high.

**Inputs:** according to the order: 4÷20mA or 0÷1V or 0÷10V

**Load1:** SPST or SPDT relay, 8(3)A, 250Vac see electrical connections

**Load2:** SPST or SPDT relay, 8(3)A, 250Vac see electrical connections


**Alarm:** **XH131C, XH131D, XH131R,:** SPST relay, 8(3)A, 250Vac

**Other output**

**XH131C, XH131D, XH131R:** buzzer for acoustical alarm  
**Data storing:** on the non-volatile memory (EEPROM).  
**Operating temperature:** 0÷60 °C (32÷140°F).  
**Relative humidity:** 20÷85% (no condensing)  
**Storage temperature:** -30÷85 °C (-22÷185°F).  
**Measuring range:** according to the probe  
**Controller Accuracy a 25°C:** better than ±0,5% of full scale


**11. CONNECTIONS**

**XH130C**




**Power supply 24Vac/dc:** connect to the terminals 8-9  
**XH20P:** connect a wire to terminal 10, and the other to terminal 11, no polarity is requested.

**XH131C,**




**Power supply 24Vac/dc:** connect to the terminals 8-9  
**XH20P:** connect a wire to terminal 10, and the other to terminal 11, no polarity is requested.

**XH130D**




**Power supply 24Vac/dc:** connect to the terminals 10-12  
**XH20P:** connect a wire to terminal 3, and the other to terminal 4, no polarity is requested.

**XH131D**




**Power supply 24Vac/dc:** connect to the terminals 10-12  
**XH20P:** connect a wire to terminal 3, and the other to terminal 4, no polarity is requested.

**XH131R (no RS485)**



**Power supply 24Vac/dc:** connect to the terminals 1-3  
**XH20P:** connect a wire to terminal 14, and the other to terminal 15

**XH131R (with RS485)**



**Power supply 24Vac/dc:** connect to the terminals 1-3  
**XH20P:** connect a wire to terminal 14, and the other to terminal 15

## 12. DEFAULT SETTING VALUES

COD	PARAMETERS	RANGE	Level	Value
Set	Set point	LS1÷US1	Pr1	0
db	Dead band	0.1/ Full Sc.	Pr1	2
LS1	Minimum set point	Down Sc./ Set	Pr2	0
US1	Maximum set point	Set./ Full Sc.	Pr2	100
ALU	MAXIMUM alarm	0= Full Sc.-Set ; or Set/ Full Sc.	Pr2	10
ALL	Minimum alarm	0= Down Sc.-Set ; or Down Sc.+Set	Pr2	10
Ald	Alarm delay	0÷999 min	Pr2	15
dAO	Alarm delay at start up	0÷999 min	Pr2	30
od	Output delay	0÷500 sec	Pr2	0
LCI <sup>1</sup>	Lower current input	According to the probe	Pr2	0
UCI <sup>1</sup>	Higher current input	According to the probe	Pr2	100
LAO <sup>2</sup>	Lower analog output limit	Lower An.Output limit	Pr2	0
UAO <sup>2</sup>	Upper analog output limit	Upper An. Output limit	Pr2	100
Opb	Probe Calibration	Down Sc./ Full Sc.	Pr2	0
Ad1 <sup>1</sup>	RS485 serial address	0÷94	Pr2	0
Ad2 <sup>2</sup>	RS485 serial address	0÷94	Pr2	1
AOC <sup>2</sup>	Analog output configuration	0= Probe; 1 Probe-set.	Pr2	0
So1	Relay 1 status with faulty probe	0=open 1=closed	Pr2	0
So2	Relay 2 status with faulty probe	0=open 1=closed	Pr2	0
Hdd	Half digit display ON/OFF	0=OFF 1=ON	Pr2	0
rES	Decimal point ON/OFF	0=OFF 1=ON	Pr2	0
ALC	Alarms configuration	0= relative 1= absolute	Pr2	0
SAO2	Analog output safety with probe fault	0= 4mA or 0Vdc; 1= 20mA or 1Vdc	Pr2	1
OnF	Switthcing ON/OFF enabling	0=not enabled; 1=enabled	Pr2	0
Ptb	Parameter table	---	Pr2	various
rEL		---	Pr2	0.4

\* only for models with analog output

Dixell s.r.l. Z.I. Via dell'Industria, 27  
 32010 Pieve d'Alpago (BL) ITALY  
 tel. +39 - 0437 - 98 33 - fax +39 - 0437 - 98 93 13  
 E-mail: dixell@dixell.com - <http://www.dixell.com>