

FRONT PANEL COMMANDS

SET1: By pressing and releasing this key the set point is displayed for 5s.

By holding the key pressed for at least 2s set point change mode is entered: the set point is displayed and the LED1 flashes. To change the value use the "UP" and "DOWN" keys. The new value can be stored either by pressing the "SET" key (the instrument restores temperature display) or by waiting the exit timeout to expire (15s).

TO SWITCH THE INSTRUMENT ON/OFF: If the function is enabled (par. OnF=1), by pressing the SET key for more than 4s the controller is switched OFF. To switch the instrument on again press the SET key.

- ▲ **(UP)** In programming mode or in "Function Menu" it browses the parameter codes or increases the value of the displayed variable. Hold pressed for a faster change.
- ▼ **(DOWN)** in programming mode or in "Function Menu" it browses the parameter codes or decreases the value of the displayed variable. Hold pressed for a faster change.

KEY COMBINATIONS:

- ▲+ ▼ hold pressed for 3s the keyboard is unlocked (see "LOC" function).
- SET1 + ▼ When held pressed for 3s the Function Menu is entered.
- SET1 + ▲ Programming end, return to the normal display.